



1. When handling the benches, fix the eyebolts to the threaded bushes (1).
2. Place the bench onto the floor and check the regulation of the feet (2).
3. Remove the eyebolts and fix cover plates (3) to the threaded bushes, sealing them with silicon.

**If you need to fix it to the ground, the following tools are required:**

1. Jackhammer
2. Nr. 4 / 6 M10 threaded rods
3. quick-setting chemical concrete

- 1) Find the installation area. Check that there are no sub-services. Make sure that the ground is leveled and solid enough (concrete, asphalt, stone or porphyry are all suitable materials).
- 2) Remove the feet and fasten the threaded rods to bench.
- 3) Mark the holes corresponding to the rods and drill the floor with diameter 20 mm, 250 mm min. deep.
- 4) Position the bench.
- 5) Proceed with fixing with mortar / chemical concrete.