



**To fix BRAVO litter bin with anchors, the following tools are required:**

1. nr.3 expansion anchors or chemical M8 (not supplied) with washers M8
2. drilling machine for cement
3. wrench hex wrench

- 1) Make sure the subfloor is adequate (concrete, asphalt, stone).
- 2) Drill holes in the ground in correspondence with the holes in the base plate of the support.
- 3) Fix the plate with anchors and washers.
- 4) Fix the liner on the support with nr. 2 round head screws M8x25 and washers (1) using the pre-set threaded inserts (2).