



Make a hole on the ground of a minimum diameter of 140 and deep. 240 and do cement the base holder of the bollard as indicated by the arrow.