



**1ST PHASE:** N° 2/4 ANCHORS (hil ti hsa-k m8\*92)

**2ND PHASE:** N°8 STAINLESS STEEL BOLTS (tbei m6\*20)

1. Place the base plate (A) on the ground and secure it with appropriate bolts (not supplied).
2. Insert the bollard (B) inside the socket and secure it with dome head screws M6x20.